



# 19381 Power Clean 1000 XT Self-Contained Extractor/Extracteur autonome

## Parts - Pièces

### Frame Assembly



### Brush Assembly



## Frame Assembly

N.	Part No.	Description	Quantity
2	3-34341	Frame	1
3	3-39528	Hose Asm, 1.5 Blk Vac X 15.5	1
4	3-41236	Hubcap, 5/8" Shaft	2
5	3-41351	Harness, Main	1
6	3-41354	Hinge, Tank To Frame	1
7	3-53640	Motor Asm, Brush	1
8	3-57030	Nut, 10-32 Hex Nylock	2
9	3-57245	Nut, 1/4-20 Hex Nylock Ss	2
10	3-99809	Foam Tape, 1/8 Thk X 3/4 1sda	2
11	3-62761	Plate, Brush Mtr Clamp	1
12	3-64099	Pulley, 1.4 Od, 6gr, Micro-v	1
13	3-66282	Plug, Hole, .375" Blk	6
14	3-66288	Plug, 9/16 Od Blk Nylon	2
15	3-70643	Scr, 1/4-20 X 3/8 Pphms	2
16	3-70066	Scr, 10-32 X 3/4 Pphms	2
18	3-87013	Washer, 1/4 Id X 5/8 Od Ss	2
19	3-87025	Washer, 1/4 Lock Ext Star Ss	2
20	3-87018	Washer, #10 X 9/16 Od	2
21	3-70074	Set Scr, 10-32 X 1/4 Kcp	2
22	3-73197	Strain Relief, 90 Degree	1
24	3-89279	Wheel, 9.75" X 1.5"	2
25	3-03107	Axle, 5/8 X 17.06l	1
26	3-99667	Heat Shrink, 3/4 Id Ul/csa	10"
27	3-73943	Seal, Frame/tank	1
28	3-20035	Clamp, 7/16 Dia Nylon Ul	1
29	3-20041	Clamp, 2.0" Worm Gear	1
30	3-70271	Scr, 1/4-20 X 1/2 Hhcs Pltd	2
31	3-70057	Scr, 1/4-20 X 1 Pphms Ss	2
32	3-66052	Pin, Roll 1/8" X 1.0" L	1
33	3-70697	Scr, 1/4-20 X 1.25 Pphms Ss	1
34	3-57105	Nut, 1/4-20 X Hex w/ Star Washer	3

## Brush Assembly


N.	Part No.	Description	Quantity
1	3-03110	Axle, Roller	1
2	3-04084	Adapter, Brush Brg.	1
3	3-09019	Bearing, 1.125odx.500idx.375	2
4	3-11045	Belt, 180j6 Micro-v	1
5	3-12515	Brush, 18l X 3.38od	1
6	3-140343	Brkt, Brush Pulley	1
7	3-140351	Brkt, Brush Height	1
8	3-34341	Frame	Ref

## Brush Assembly (Continued)


N.	Part No.	Description	Quantity
9	3-36192	Guard, Thread	2
10	3-41346	Housing, Brush 18"	1
11	3-50998	Label, Brush Height	1
12	3-51311	Linkage, Asm, Brush Height	1
13	3-51312	Linkage Asm, Roller Support	1
14	3-51314	Link, Roller, Front	2
15	3-51317	Lever, Height Adjustment	1
16	3-57030	Nut, 10-32 Hex Nylock	4
17	3-57271	Nut, 3/8 Dia Cap, Type Push Plt	2
18	3-62758	Plate, Brush Housing Rh	1
19	3-62759	Plate, Brush Housing Lh	1
20	3-62762	Plate, Axle Retainer	2
21	3-64098	Pulley, 2.2 Od, 6gr, Micro-v	1
22	3-66192	Pin, Roll 1/4 X 1.25l	1
23	3-67411	Roller, 1.9 Dia X 10.5 Lg	1
24	3-70043	Scr, 10-32 X 5/8 Pfhms	2
25	3-70088	Scr, 10-32 X 1/2 Pphms Ss DI	6
26	3-70177	Scr, 10-32 X 1/2 Fhms Ss	7
27	3-70232	Scr, 10-32 X 3/8 Fhms Ss	2
28	3-70497	Scr, #10-24 X 1/2 Shcs	2
29	3-87016	Washer, #10 Lock Ext Star Ss	4
30	3-87018	Washer, #10 X 9/16 Od	6
31	3-70675	Scr, 1/4-20 X.5/8 Thms Pltd Np	4
32	3-67467	Ring, Tolerance 7/8 ID X 1/2 W	1
33	3-12525	Brush, 18L X 3.38 OD G2	1
34	3-27805	Clip, Bearing	1
35	3-29157	Driver, Brush	1
36	3-70767	Shldr Bolt 3/8 OD X 3/8 L Ss NP	1
37	3-67094	Ring, 1/2 Ext. Snap	1
38	3-66310	Pin, Clevis 1/4 X 1/2 Pltd	2
39	3-80604	Cotter, 1/4" Ring	2
41	3-64102	Pulley Asm, Brush	1
42	3-29208	Driver Asm, Brush	1
43	3-12515	Brush Asm, 18 In	1
44	3-05158	Adapter Brush Brg Die Cast	1
45	3-09137	Bearing, R6 3/8 Id	2
46	3-47383	Brush bearing Asm	1
47	3-47416	Kit, Brng/Adaptor Extractor	Ref

**Parts - Pièces**


**Pump Assembly**



**Vacuum Shoe Assembly**



**Control Panel Assembly**



## Pump Assembly

N.	Part No.	Description	Quantity
1	3-22072	Coupling, 1/4 Anchor W/1" Hex	1
2	3-22090	Connector, 1/8fpt X 1/4 Tube, Qc	2
3	3-31072	Elbow, Swivel, 1/4mptx1/4tube, Qc	1
4	3-31074	Elbow, Swivel,3/8mptx3/8tube, Qc	1
5	3-44067	Jet Body	2
6	3-44068	Jet, 9504	2
7	3-57030	Nut, 10-32 Hex Nylock	2
8	3-65201	Pump Asm	1
9	3-66288	Plug, 9/16 Od Blk Nylon	2
10	3-70195	Scr, 10-32 X 1.25 Pphms	2
11	3-70011	Scr, 1/4-20 X 5/8 Hhcs Ss	2
12	3-34355	Fitting,1/4 Tube,"y", Qc	1
13	3-78419	Tee, 3/8 Mpt X 3/8 Tube, Qc	1
14	3-84160	Valve Asm, Solenoid	1
15	3-87191	Washer, 1/4"idx1.0od. Flat Ss	2
16	3-87018	Washer, #10 X 9/16 Od	4
17	3-87192	Washer, 7/16 X 3/4 X .19rubber	2
18	3-56014	Nipple, 1/4 Close	1
19	3-56012	Nipple, 1/4 Fpt Qd	1
20	3-31076	Elbow, 1/4 Mpt X 3/8 Tube, Qc	2
21	3-70162	Scr, 10-32 X 3/8 Pphms Ss	2
23	3-880278	Wire, 22" Grn/18 76011 X 76011	1
24	3-39529	Hose, 3/8 Urethane X 29"	1
25	3-39530	Hose, 3/8 Nylon X 6"	1
26	3-39531	Hose, 1/4 Urethane X 6"	3
27	3-73963	Screen, Intake	1
28	3-39591	Hose, 3/8 Nylon X 29"	1
29	3-31022	Elbow, 1/8 Npt Street	1


## Vacuum Shoe Assembly

N.	Part No.	Description	Quantity
1	3-05016	Arm, Vac Shoe Parallel	4
2	3-27674	Cover, Accessory Port	1
3	3-57245	Nut, 1/4-20 Hex Nylock Ss	4
4	3-70351	Scr, 10-32 X 3/8 Hhtr W/star	2
5	3-70360	Scr, 1/4-20 X.75 Pphms Phil	4
6	3-70390	Scr, 1/4-20 X 1 Fhcs Pltd	4
7	3-73958	Spacer, 3/8odx.058wx.2814,crs	8
8	3-85040	Vac Shoe, 18"	1
10	3-87013	Washer, 1/4 Id X 5/8 Od Ss	4
11	3-87074	Washer, Wave 3/8id X3/4d X.125	8
12	3-35171	Gasket, Accessory Port	1
13	3-73955	Spring, Ext .38d X 2.75l X .055w	2


## Control Panel Assembly

N.	Part No.	Description	Quantity
1	3-14020	Terminal Block, 115v (3-4-3)	1
2	3-14700	Breaker, 15a 250vac 50vdc	1
3	3-14832	Breaker, 6a Vde Circuit	1
4	3-14942	Boot, 3/8 Circuit Breaker	2
5	3-23679	Cord Asm, 14/3 X 22" Ylw	1
6	-	Cover, Panel	1
7	3-35248	Gasket, Panel	1
8	3-41351	Harness, Main	1
9	3-57040	Nut, 1/2 Npt Conduit	2
10	3-57104	Nut, 10-32 W/star Washer Pltd	3
11	3-57116	Nut, 6-32 W/star Washer Pltd	2
12	3-70235	Scr, 6-32 X 1.0 Ph Blk Nylon	2
13	3-70066	Scr, 10-32 X 3/4 Pphms	1
14	3-72126	Switch, Dpdt 3-position Rocker	1
15	3-72130	Switch, Spst 2-position Rocker	2
16	3-73195	Strain Relief, 1/2 Npt Trumpet	2
17	3-87100	Washer, 3/8 Id Int.lock Thin	2
18	3-500226	Label, Circuit Breaker Brush	1
19	3-500225	Label, Circuit Breaker Vac	1
20	3-500154	Label, Control Panel	1
21	3-50279	Label, Ground Symbol	1
22	3-87189	Washer,10 Fly Stl Blk Znplt	7
23	3-70626	Scr, #10 X 3/4 Pphst Hi-lo Blk	7

Parts - Pièces  
Handle Assembly



Solution Tank Assembly



## Handle Assembly

N.	Part No.	Description	Quantity
1	3-03109	Axle, Handle	1
2	3-20084	Clamp, Handle Lock	2
3	3-23086	Cord Set,14/3 Sjt-w-a X 50'Ylw	1
4	3-27371	Clip, Power Cord	2
5	3-500514	Label	1
6	3-36046	Grip, Handle X 13"	1
7	3-38289	Handle, Control	1
8	3-48012	Knob, 5/16-18 4 Prong	1
9	3-51039	Lever, Handle Clamp	1
10	3-51313	Link, Handle Adj.	2
11	3-57113	Nut, 5/16-18 Hex Nylock	2
12	3-61350	Control Panel	1
13	3-66068	Pin, Roll 1/8" X 5/8"l	1
14	3-67073	Rod, Handle Lock	1
15	3-67147	Ring, 2" Dia Split	1
16	3-70249	Scr, 1/4-20 X 1.25 Hhcs Pltd	4
17	3-70351	Scr, 10-32 X 3/8 Hhtr W/star	1
18	3-70532	Scr, 10-32 X 1/2 Pphms Blk Np	7
19	3-73169	Strain Relief, Cord Hook	1
20	3-73180	Spacer, .50 Odx.058wx9.84l Crs	1
21	3-87025	Washer, 1/4 Lock Ext Star Ss	4
22	3-87029	Washer, 5/16 Flat Ss	2
23	3-87189	Washer, .2l dx.500 Blk Ss	7

## Solution Tank Assembly

N.	Part No.	Description	Quantity
1	3-20041	Clamp, 2.0" Worm Gear	2
2	3-20042	Clamp, 3/8 Hose (d-slot)	2
3	3-27809	Cover, Vac Motor	1
4	3-27810	Cover, Belt	1
5	3-31081	Elbow, 3/8 Mpt X 3/8 Tube, Plastic	1
6	3-35175	Gasket, Tank To Vac Cover	2
7	3-35231	Gasket, Vac Cover	2
8	3-39526	Hose, 1/2 Clear X 12	1
9	3-39536	Hose, 1.5 Blk Vac X 5.0	1
10	3-39528	Hose Asm, 1.5 Blk Vac X 15.5	Ref
11	3-41348	Housing, Vac Motor	1
12	3-53789	Vac Motor Asm	1
12A	3-14258	Brush Set, 120V 5.7 Vac	-
12B	3-140687	Brush Set, 120V Vac	-
13	3-70525	Scr, #10 X 1.0 Pphst Type B	6
14	3-75399	Tank, Solution	1
15	3-85038	Vent, Cooling Air Lrg	1
16	3-87018	Washer, #10 X 9/16 Od	10
17	3-73864	Strainer, 3/8 In. Npt 60 Mesh	1
18	3-87013	Washer, 1/4 Id X 5/8 Od Ss	5
19	3-70085	Scr, 1/4-20 X 1/2 Pphms Ss DI	3
20	3-20092	Clamp, 3.5" Worm Gear	1
21	3-35236	Gasket, Tank, L-f	1
22	3-35237	Gasket, Tank, L-r	1
23	3-35238	Gasket, Tank, Rh	1
24	3-40027	Hosebarb, 3/8mptx1/2 90d DI	1
25	3-70360	Scr, 1/4-20 X.75 Pphms Phil	2
26	3-87025	Washer, 1/4 Lock Ext Star Ss	2
27	3-70114	Scr, #10 X 3/4 Pphst Type B	4
28	3-89183	Weldment, Handle Pivot	1
29	3-57245	Nut, 1/4-20 Hex Nylock Ss	2
30	3-02130	Hose Assy- Fill Hose	1
31	3-20016	Clamp, 1/4 Id Hose	1
32	3-40023	Hosebarb, 1/2Mpt X 3/8 DI	1



## Recovery Tank Assembly

N.	Part No.	Description	Quantity
1A	3-20064	Clamp, 2.0" Worm Gear X .312	1
1B	3-20002	Clamp, 2.00 Nylon Ratchet	1
2	3-20041	Clamp, 2.0" Worm Gear	1
3	3-27670	Cord, Drain Plug	1
4	3-27816	Cover, Rec. Tank	2
5	3-28060	Dome	1
6	3-34351	Float Shut-off	1
7	3-35230	Gasket, Dome	1
8	3-35232	Gasket, Port Cover	2
9	3-39353	Hose, 1.5 X 12.0 Drain	1
10A	3-41391	Hose, Insert	1
10B	3-40019	Hosebarb, 1.5 Double Mchd	1
11A	3-41390	Hose, Cap	1
11B	3-66227	Plug, Drain Hose	1
12	3-70114	Scr, #10 X 3/4 Pphst Type B	6
13	3-75402	Tank, Recovery	1
14A	3-140408	Brkt, Hose Hook	1
14B	3-140133	Brkt, Recovery Hose Mtg	1
15	3-27417	Cord, 99807 1/8 X 12"	1
16	3-500009	Label, Warning	1
17	3-500159	Label, Main	1
18	3-28061	Dome Asm	1

## Suggested Spare Parts

N.	Part No.	Description	Quantity
-	3-12514	Brush, 15l X 3.38od	-
-	3-11045	Belt, 180j6 Micro-v	-
-	3-09019	Bearing, 1.125odx.500idx.375	-
-	3-44067	Jet Body	-
-	3-44073	Jet, 8003	-
-	3-65201	Pump Asm	-
-	3-84160	Valve Asm, Solenoid	-
-	3-35171	Gasket, Accessory Port	-
-	3-14700	Breaker, 15a 250vac 50vdc	-
-	3-14832	Breaker, 6a Vde Circuit	-
-	3-72130	Switch, Spst 2-position Rocker	-
-	3-72162	Switch, Dpdt3-position Rocker	-
-	3-53789	Vac Motor Asm	-
-	3-73864	Strainer, 3/8 In. Npt 60 Mesh	-
-	3-28061	Dome Asm	-
-	3-34351	Float Shut-off	-
-	3-66227	Plug, Drain Hose	-
-	3-14258	Brush Set, 120v 5.7 Vac	-
-	3-140687	Brush Set, 120v Vac	-